

BMW OUTPUT SHAFT KIT



*For removing and installing output shaft in drive flange as well as for removing front wheel bearing unit.

Rating: Not Rated Yet

Price:

Sales price:

Discount:

[Ask a question about this product](#)

Manufacturer: [HCB Specialty Tools](#)

Description

Product Description :

2008 BMW OUTPUT SHAFT KIT

Product Description :

BMW OUTPUT SHAFT KIT

?Product Info?

Model/Item No. :

H.C.B-A1253

Country of Origin :

Taiwan

Brand :

H.C.B

Product Specifications /Features :

*For removing and installing output shaft in drive flange as well as for removing front wheel bearing unit.

*Applicable: BMWE30, E31,E32, E36, E39, E46, E52, E53, E60, E63, E64, E65, E66, E67, E83, E85, RR1, (On E53 used in conjunction with H.C.B-B1253)

***CONTENTS & ASSOCIATED TOOLS:**

1.HUB Puller Plate

2.Clamping Apparatus

3.Force Screw M20 * P1.5, Length: 150mm

Used to press output shaft out of drive flange, grip with tire iron in so doing. Applicable: E30, E31, E32, E36, E38, E39, E46, E53, E65, E66, E67, E83, E85

4.Output Shaft Adaptor -M22 * P1.5,
Used to insert output shaft into drive flange. Applicable:
E30

5.Output Shaft Adaptor – M27 * P1.5,
Used to insert output shaft into drive flange.
Applicable:E31, E52, E53, E60, E61, E65, E66, E67, E83

6.Output Shaft Adaptor – M24 * P1.5
Used to insert output shaft into drive flange.
Applicable:E36, E46

7.FORCE NUT AND BEARING

8. FORCE SCREW
Applicable: E30, E31, E32, E36, E38, E39, E46, E52, E53,
E60, E61, E65, E66, E67, E83, E85, RR1

9.Output Shaft Adaptor-M30*P1.5

Primary Competitive Advantages :

Well and High Quality Control, Prompt Delivery, New Product, Customer'l's Design and Logo are Welcome, Competitive Prices

Sales Method :

Export, Manufacture

Payment Term :

T/T, L/C at Sight

on car :

PRESSING OUTPUT SHAFT OUT

- 
- Insert the Force Screw A1253-3 into the Force Screw A1253-7 and install through HUB Puller Plate A1253-4
 - Attach the Puller Plate A1253-1 securely to the drive flange with the original wheel studs.
 - Screw special tool A1253-5, grip with the iron A1253-2 and H.C.B-C1253, and then press output shaft out of drive flange.

INSTALLATION OF OUTPUT SHAFT

- 
- 
- Lightly oil output shaft of output shaft.
 - Insert output shaft into drive flange.
 - Insert correct Output Shaft Adaptor A1253-4, 5, 6, 8 from special tool kit H.C.B-A1253 and screw onto output shaft.
 - Screw on special tool A1253-1 with wheel studs.
 - Draw in output shaft with special tool A1253-8 and A1253-3, grip with the iron A1253-2 and H.C.B-C1253 in so doing.